Accessories for HAKKO FX-888D & FX-889

Packing List			
FX-8801	Handpiece, Instruction Manual		
FX-8802	Handpiece, Shield plate, Instruction manual		
FX-8803	Handpiece, Instruction manual		
FX-8804	Handpiece, Caution label, Heat resistant pad, Instruction manual		
FX-8805	Handpiece, Instruction Manual		

NOTE: The soldering iron cannot be used as a standalone device.

Option

FX-8803

Part No.	Name	Specifications
C1437	Iron holder (with cleaning sponge)	-

FX-8804

Part No.	Name	Specifications	
FH800-04BY	Iron holder (with cleaning sponge)	Blue & yellow	

FX-8801 & FX-8805

Part No.	Name	Specifications
B5122	Tip enclosure	With nut, required when converting from the FX-8801 to the FX-8805
B3730	Nut and tip enclosure	Required when converting from the FX-8805 to the FX-8801

Replacement Tips for the FX-8801 and FX-8803

Unit: mm

	Treplacement rips for the 1% door and 1% door					
Applicable for FX-8803 T18-B Shape-B	Applicable for FX-8803 T18-SB Shape-SB	T18-BR02 Shape-0.2BR	T18-BL Shape-BL	T18-C05 Shape-0.5C		
© *Pos 14.5	(a) About 13.2	10.5	22.5	45° 13.5		
Applicable for FX-8803 T18-C08 Shape-0.8C	T18-C1 Shape-1C T18-CF1*	T18-CF15* Shape-1.5C	Applicable for FX-8803 T18-C2 Shape-2C T18-CF2*	Applicable for FX-8803 T18-CSF25* Shape-2.5CS		
A5 15.5	95	90 90 13.5	25 14.5	7.5 A5		
Applicable for FX-8803 T18-C3 Shape-3C T18-CF3*	Applicable for FX-8803 T18-C4 Shape-4C T18-CF4*	T18-C5 Shape-5C	Applicable for FX-8803 T18-K Shape-K	T18-D08 Shape-0.8D		
32 45 14.5	A6 14.5	A5 14.5	2 45° 14	0.6		
T18-D12 Shape-1.2D	Applicable for FX-8803 T18-D16 Shape-1.6D	Applicable for FX-8803 T18-D24 Shape-2.4D	Applicable for FX-8803 T18-D32 Shape-3.2D	T18-DL12 Shape-1.2DL		
0.7	0.5	0.5 14.5	0.5 14.5	0.7		
T18-DL2 Shape-2DL	T18-DL32 Shape-3.2DL	T18-S3 Shape-S3	Applicable for FX-8803 T18-S4 Shape-S4	T18-S6 Shape-S6		
© 22.5	1 22.5	1 18	14.5	60° 16.5		
T18-S9 Shape-S9	T18-I Shape-I					

 * These tips are tinned on the soldering surface only.