ø8 A8 Series Accessories

Shape	Material		Part No.	Ordering Part No.	Package Quantity	Remarks	ot Lights
Locking Ring Wrench	Metal (nickel-plated brass)		MT-004	MT-004	1	Used to tighten the locking ring when installing the A8 series into a panel.	APEM
Switch Guard	90° open	For round/square Unit	AL-K8	AL-K8	1	Used to protect pushbuttons from inadvertent operation. See B-393 for dimensions. (remains 90° open)	Switches & Pilot Lights Control Boxe
		For rectangular unit	AL-KH8	AL-KH8	1		Emergency Stop Switch Enabling Switches
Socket	Solder Terminal		AL-C8	AL-C8	1	Snaps on the rear of the A8 series. (see B-393 for dimensions)	Safety Produ
	PC Board Terminal		AL-C8V	AL-C8V	1		Terminal Blo
Terminal Cover	Nylon		AL-V8	AL-V8PN10	10	When wiring the terminals, insert the lead wires into the terminal cover holes before soldering. Terminal cover is not attached and must be ordered separately.	Circuit Protectors Power Suppi LED Illumina Controllers
Mounting Hole Plug	Nitryl rubber (black)		AL-B8	AL-B8PN05	5	Degree of protection: IP65	Operator Interfaces Sensors AUTO-ID

hes

plies

nation

Flush Silhouette

ø16

ø22 ø30

Pilot Lights

LD6A