

### 7.4.2 Connection Device Registration

■Function

This registration is not required if no wireless unit is to be connected.

To connect a measurement device through the wireless master unit, first register the wireless master unit and the wireless/RS-485 converter as a connection device.

A wireless sensor or a RS-485-connected connection device must be registered as a measurement device connected to the wireless master unit or wireless/RS-485 converter registered as its connection device.

Whether a device should be registered as a connection device or a measurement device depends on the measurement function.

See below for registration.

Wireless Unit Type	Function	Registration
Wireless Unit Master WZ-MLAN01	Wireless Master Unit (No measurement function, relaying only)	Register as a connection device
Wireless Unit Slave (CompoWay/F) WZ-SRS01	Wireless RS-485 converter (No measurement function, relaying only)	
Wireless Device Unit	Wireless Slave Unit (with measurement function)	Register as a measurement device with a connection device as its destination
An RS-485-connected device to be connected to a wireless/RS-485 converter	Wireless Device (with measurement function)	

