
[High Precision] Z-Axis Dovetail Slide, Feed Screw

Extended Knob / Reinforced Clamp



Part Number Stage Surface Travel Distance Travel Der Rotation Load Capacity Travel Accuracy Moment Load Capacity (N · m) Weight Accessory (4 pcs.)												
Part Number		Stage Surface	Travel Distance	Iravel per Rotation	Load Capacity	Iravel Accuracy	Moment Load Capacity (N · m)			Weight		Unit Price
Type	No.	(mm)	(mm)	(mm)	(N)	Straightness (µm)	Pitching	Yawing	Rolling	(kg)	Type M-L	Ollit Frice
	25	25x25	±5		9.8		2.0	1.5	1.5	0.12	SCB2-8	
ZEGL	40	40x40	±7	0.5	9.8	30	4.0	3.0	3.0	0.27	SCB3-8	
	60	60v60	+0		10.6		5.0	4.0	4.0	0.71	SCR4-10	

Resolution (Vernier Scale Indication): 0.1 mm/division

* The depth will be short due to the stage shape.

- Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended. 🗷 P.2004
- TXY-Axis Mounting Plate XPLTE: Use this plate when connecting stages with non-matching mounting holes. 🗷 P.1915

Features: Z-Axis stage feed knob shaft is directly clamped with a split clamp for improved position holding performance.






MMaterial: (Main Body) Low Cadmium Brass Surface Treatment: Black Fluororesin Treatment

(Feed Knob) Low Cadmium Brass





	Part Number		Stage Surface	Travel Distance	Travel per Rotation	Load Capacity	Travel Accuracy	Moment Load Capacity (N · m)			Weight	Accessory (4 pcs.)	Unit Price
- [Type	No.	(mm)	(mm)	(mm)	(N)	Straightness (µm)	Pitching	Yawing	Rolling	(kg)	Type M-L	Unit Price
ZEGCL	25	25x25	±5	0.5	9.8	30	2.0	1.5	1.5	0.10	SCB2-8		
	40	40x40	±7		9.8		4.0	3.0	3.0	0.27	SCB3-8		
	60	60x60	±9		19.6		5.0	4.0	4.0	0.71	SCB4-10		

- Resolution (Vernier Scale Indication): 0.1 mm/division
- **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extended.
 **Extension Cover HDEXT12 (Sold Separately): Ø12 feed screw knob can be extension cover feed screw knob can b
- There will be residual clearances with carriage retaining only with a Reinforced Clamp. Use a Clamp Screw in combination.



See the CAD data for When alteration R is ecified for ZEGCL reinforced clamp positio

