

## **AC Adapters for Ionizers / Nozzle Attachments**

**Tube Type / Stainless Steel Bar Type** 








Part Number	Nominal	Unit Price
ENZR-T (Tube Type)	-	
ENZR-R1 (Pin Hole Type)	200	
ENZR-R2 (Bar Type)	200	


Features
Tube Type can reach near the working area freely.
Select R1 for pinpoint neutralization accuracy, R2 for neutralization in stripes.

Tree sample consignment available. For details, P495



How to Handle

①Confirm that the main power is OFF, and remove the cable strain relief and the washer (black) from ENZR-R.



**ENZR-R1** 

2)Attach the cap of the attachment to the main body. Tube Type can be cut by the arbitrary

length for use.

③Fix the tube of Tube Type with the Included fixing metal.

