


## **Casters with Leveling Mounts**

## **Antivibration**










Part Number - Wheel Material Ordering Example CLDK65







1)Turn the adjusting handwheel and raise / lower the pad.



- \* Adjusting handwheel and adjusting nut are integrated.
- 1) Turn the handwheel to lower the pad to the ground. (Temporary tightening)
- 2) After confirming the height, fully tighten the nut beneath the handwheel. Standing on the pad only, the caster is elevated above the ground.
- 3 Tighten the lock nut.

(Torque applied by the lock nut gives loosening prevention effect against vibration.)

- · Free
- ③Loosen the lock nut.
- (2)Loosen the adjusting nut to release the screw.
- ①Turn the handwheel to raise the pad and lower the caster to the ground.